

TUFFROK



Discovery 3/LR3 Power panel

Fitting Instructions

Please read the tips below very carefully.

The Discovery 3/Lr3 power panel has been professionally measured and manufactured to fit

We use the original fixings in the vehicle to minimize any changes being made.





Fig2

1. We recommend using these pics for reference to wire the panel as shown in Fig2 and Fig3. However, you may choose to do it differently.



Fig3



Fig4

2. Remove this part of the dash by simply applying small force as shown in Fig4. The silver panel surround will come away, it will expose 2 x fixings on the ashtray. Remove the old ashtray panel and fit your new Tuff-Rok one as shown in Fig5 using existing power that was either side of the old Ashtray



Fig5

3. Refix Dash panel that you removed in Fig4 and the Job is done!



TUFF ROK

Follow us on Instagram ([landrover_tuffrok](https://www.instagram.com/landrover_tuffrok))

Find all our other items at [Tuff-rok.co.uk](https://www.tuff-rok.co.uk)

