## LIGHTS, LENSES & BULBS

## **WIRING HARNESS & FITTINGS**

Description	Qty	Part #		
HEADLIGHT				
Headlight Assembly, all Models	2	* <b>NLA</b> 5265		
Gasket, Headlight & Outer Housing & Fender	2	7591 * <b>NLA</b> 1952		
Headlight Rim, Chromed, Head only Gasket, Rubber Headlight Rim	2 2 2 2 2	NLA 1952 NLS		
Gasket, Headlight Housing & Grill Panel	2	7590		
Headlamp Bowl, 7" (Full Kit)	2	4000		
Headlamp Bowl Mounting Ring	2	* <b>NLA</b> 3545		
Headlamp Fixing Kit See Body Parts for additional information	2	* <b>NLA</b> 3511		
PARKING & TURN LAMPS - FRONT				
→ LAMP KIT	KIT	3604		
Includes: 2 Front Parking Lamp, 2 Stop & Tail Lamps				
Lamp Assembly, Clear, Conical Plastic Lens	2	6962		
Lens for Assembly 6962, Clear Plastic	2	5558		
Lamp Assembly, Amber Conical Plastic Lens Lens for Assembly 3602, Amber Plastic	2 1	3602 3603		
Lens. Amber Conical Glass	2	* <b>NLA</b> 7534		
STOP & TURN I AMPS - REAR	_			
Lamp Assembly, Stop & Tail, Red, Conical, Plas	stic			
(current European)	2	3736		
Lens for Assembly 3736, Red Plastic	1	3737		
Lamp Assembly, Stop & Tail, Steel Body, Plastic Lens. IIA	2	7524		
Lens for Assemby 7524, Plastic	1	* <b>NLA</b> 6370		
Turn Signal Assembly, Amber, plastic				
(current European)	4	3602		
Lens for Assembly 3602, Amber Plastic	4	3603		
SIDE LAMPS				
Lamp Assembly, Front Amber, Replacement (current model)	2	AMR2036		
Lens, Amber, Original	1	7533		
Lamp Assembly, Rear Red				
Replacement (current model)	2	AMR2037		
Lens, Red, Square Original Reflector, Red, Original	1 1	* <b>NLA</b> 7532 * <b>NLA</b> 7570		
<del>-</del>	1	NLA 1310		
OTHER LAMPS Backup Lamp Assembly	2	* <b>NLA</b> 7563		
Lens for Assembly 7563, Plastic	1	* <b>NLA</b> 7581		
License Plate Light Assembly	1	7539		
Lens for Assembly 7539, Clear Glass	1	7540		
Dome Light Assembly Lens for Dome Lamp	1 1	6186 7578		
•	1	1310		
BULBS Headlamp Replacement				
Halogen Sealed Beams (pair)	1	* <b>NLA</b> 2923		
Headlamp, Replacement, European	1	9691		
Headlamp, Replacement, Off-road	2	9665		
Replacement Bulb H,4	1 2	9667 5378		
Parking Lamp Bulb, Small Base, early IIA Parking Lamp Bulb, Large Base, Later Models		10211		
Brake & Tail Light Bulb	2 2	1870		
Turn Signal, Flasher Bulb	4	1868		
Side Marker Bulb, (original) License Plate Bulb	4	5378 5378		
Backup Lamp Bulb	2 2	7568		
Dome Light Bulb	1	1868		
Panel Light, Series III	4	503352		
	needed 1			
Hazard Warning Switch Bulb	ı	* <b>NLA</b> 7592		
*N/ A = No longer available				
*NLA = No longer available.				

Year	Description	Qty	Part #		
WIRING	G HARNESSES PB-PVC Coated Wires, Braided Outer Cover	ina			
48-49	Landrover, 4 wheel drive, 80" Chassis, NF96 Regulator Separate Fuse box, 1.6 L Petrol E Chassis #860,001 - 6,105830, PB	-	* <b>NLA</b> 6620A		
49-50	Landrover, 4 wheel drive, 80" Chassis, NF95 Regulator, 1.6 L Petrol Engine,				
50-51	Chassis 6,105, 831 - 6,111,546, PB Landrover, 4 wheel drive, 80" chassis, 7" He- 1.6 L Petrol Engine, Chassis #6,111,547 -	adlamps,	* <b>NLA</b> 6620B		
51-53	16,103,898 PB Landrover, 4 wheel drive, 80" chassis, RB 106 Regulator, L Petrol Engines, separat	a fusa hov	6620C		
53-55	1.6 L & 2.0 Chassis # 16,103,899 - on , PB Landrover, 4 wheel drive, 86" chassis,		* <b>NLA</b> 6620D		
56-57	2.0 L Petrol Engine, Chassis # 47,100,001 - Landrover, 4 wheel drive, 88" Chassis, 2.0 L Engine, Dip Switch on floor, Horn on Bulkhea	Petrol	* <b>NLA</b> 6620E		
SERIES	Chassis # 121,6000,001 - up, PB	~~,	* <b>NLA</b> 6620F		
58-60	Landrover Main Positive Earth, Main & Tail, 2 Chassis # 14,180,001 - on, Braid Wrap		6620G		
(Below, 60-65	Main & Tail are now listed separately and all v Landrover Main Pos. Earth, 2.25 L Petrol En Chassis #24,100,001A up to/inc. suffix C		/C) 6620H		
66-71	Landrover Main Neg. Earth, 2.25 L Petrol En Chassis # Suffix D to Suffix H	gine	6620J		
72 on 60-74 60-71	Landrover, Main Wiring Harness, PVC Warp Landrover Tail, 88" Chassis, PVC Landrover Tail, 109" Chassis, PVC		6620K 6620L 6620M		
69-on	Landrover Wiper Motor Harness, PVC Landrover Reverse Switch Harness (now incl. i Landrover Ignition Switch Harness	n 6620H)	6620N * <b>NLA</b> 6620P * <b>NLA</b> 6620Q		
MISCE!	LLANEOUS Wiring Pigtail - Headlight	2	6620R		
All	Lead, Starter Motor to Ground	1	1375		
IIA 48-68	Lead, Battery to Ground Fuse Box Assembly, I & II	1 1	* <b>NLA</b> 1443 * <b>NLA</b> 5996		
69 on	Fuse Box Assembly, III	1	7001		
60-68	Fuse Box Cover, Early Box	1	5515		
All	Fuse, 35 amp	as needed			
All All	Junction Box, Front or Rear Battery Hold Down	1 1	* <b>NLA</b> 6615 6866		
All	Hold Down Bolt, 5-3/4"	1	* <b>NLA</b> 7019		
All	Hold Down Bolt, 7-1/4"	1	6870		
All	Wing Nut, Battery Bolts	2	597		
FITTING	GS 2-Way Connector Tube (female)	as needed	7574		
All	4-Way Connector Tube (female)	as needed			
All	6-Way Connector Tube (female)		* <b>NLA</b> 7575		
All	Snap Plug, end (male)	as needed	* <b>NLA</b> 7576		
All	Dash Socket, Red	as needed			
All All	Plug for Dash Sockets Ground Clip	as needed as needed	* <b>NLA</b> 7557 7595		
'''	*NLA = No longer available.				

## **SWITCHES**

## **INSTRUMENTS/GAUGES**

Description	Part #			
IGNITION				
Ignition Switch, IIA, Suffix "D" on (Solenoid type)	5667			
Lock & Key for Switch 5667 & 7565	2016			
Ignition & Lights thru Suffix "C"	7565			
(does not include Headlight Knob or Lock/Key)				
Headlight Knob for Switch 7565	* <b>NLA</b> 7560			
Ignition & Light thru Suffix "C", Replacement	7565A			
Starter Switch, Push Type	2073			
Knob for Starter Switch 2073	5926			
Ignition Switch, Diesel	* <b>NLA</b> 8166			
TURN SIGNAL				
Turn Signal, Dimmer, Horn, Series III	6742			
Turn Signal, Column Mounted	5279			
Bulb for Switch 5279	7547			
Bulb for Turn Signal Indicator (6742)	5400			
Flasher Unit, Turn Signal, 1969 on (2 prong)	7046			
Flasher Unit, Turn Signal, thru 1968 (3 prong)	4068			
HAZARD FLASHERS				
Hazard Warning, four way, Series III	7564			
Knob for 7564	386			
Bulb for 7564	* <b>NLA</b> 7592			
Flasher Unit for Hazard Warning Switch,				
1969 on (2 prong)	* <b>NLA</b> 7584			
Heavy Duty Flasher - Recommended if towing	7561			
CWITCHES DACH DANEL HEAD LAMD				
SWITCHES, DASH PANEL, HEAD LAMP	4004			
Dimmer Switch, Floor Mounted, 1961-72	1891			
Panel Light, Dome Light on any 12V application, Toggle Panel Light, Dome Light on any 12V Application,	6495			
	* <b>NLA</b> 2020			
Push/Pull Headlights, Parking, Heater Hi, Low,	NLA 2020			
IIA "D" & III, 3-position Toggle	5650			
Switch for Wiper/Washer, IIA "F" & III, 2-speed	7553			
Switch for Single Speed Wiper	7555 5651			
Dip Switch, 58-60	325			
Dip Switch, 30-00	323			
MISCELLANEOUS SWITCHES				
Reverse Lamp, found on Transmission	7562			
Brake Light, Power Assisted, IIA "F" & III	7566			
Brake Light, Hydraulic, Series II & IIA, "E"	5751			
Oil Pressure Switch for Green Light, IIA & III	1958			
Dash Socket - Black	* <b>NLA</b> 1555			
Dash Socket, Red	1556			
Dash Plug for 1555 & 1556	* <b>NLA</b> 7557			
Choke Light Switch, Late IIA & III (yellow light)	* <b>NLA</b> 350			
*NLA = No longer available.				

Some items in this section may be available on a special order basis or phone-order only. Please call for pricing and availability.

Description	Qty	Part #			
SPEEDOMETER					
Speedometer, 88", w/Trip, Warning Lights,					
Series III	1	2837			
Speedometer, 88" w/Warning Lights,					
Series IIA, '69-'71 (Special Order)	1	* <b>NLA</b> 6788			
Speedometer, I,II,IIA, thru Suffix "C"	1	5823			
(Special Order)					
Speedometer, I, II, IIA 109", 88" w/16" Tires	1	5601			
(Special Order)	1	F0F7			
Speedometer, IIA, 109 6 cyl. (Special Order)	ı	5657			
SPEEDOMETER CABLE					
Speedometer Cable & Casing, I,II,IIA	1	759			
Speedometer Cable & Casing, III	1	6611			
Reset Cable, Trip Odometer	1	6614			
Cable, Inner Series I, w/nylon Ferrule	1	1538			
Speedometer Clip, Series III	1	* <b>NLA</b> 1311			
Set Screw Speedo-Cable to Housing	1	1333			
GAS GAUGE & SENDER UNITS					
Gas Gauge, 88 & 109, Suffix "D" on	1	* <b>NLA</b> 6501			
Gas Gauge, 88 & 109 Regular (before Suffix "D")	1	* <b>NLA</b> 3028			
Gas Gauge, 109 Station Wagon	1	5490			
Tank Sending Unit, 88 & 109 Regular, Suffix "D" on	1	6049			
Tank Sending Unit, 109 Station Wagon,	ı	0049			
Suffix "D" on	1	6065			
Tank Sending Unit, 88 & 109 Regular	1	* <b>NLA</b> 3024			
Tank Sending Unit, 109 Station Wagon	1	* <b>NLA</b> 5408			
NOTE: 3024 & 5408 may be used on Diesels, h	oweve	r the			
warning light for low fuel will not operate.					
TEMPERATURE GAUGE					
Engine Temperature Gauge, IIA, Suffix "D" on	1	* <b>NLA</b> 6500			
Sending Unit for Gauge 6500	1	6026			
VOLTAGE GAUGE					
Voltage Gauge	1	* <b>NLA</b> 2824			
voltage Gauge	'	NEA 2024			
AMMETER					
Ammeter, Series I, II, IIA Suffix "C"	1	7585			
Ammeter, Calibrated 50-0-50 amps,					
2 1/32" lighted	1	* <b>NLA</b> 2828			
OIL PRESSURE		40			
Switch, Oil Pressure Warning Light, IIA & III	1	1958			
Gauge, Oil Pressure, Electric	1	* <b>NLA</b> 329			
Sending Unit for 329 Oil Pipe, Dual Gauge, Flexible, II/IIA	1	329A 2097			
Oil Pipe, Dual Gauge, Flexible, II/IIA Switch, Oil Pressure, Series II	1 1	2097 241			
Switch, Oil Flessule, Selles II	ı	4 <del>4</del> I			

\*NLA = No longer available.